

# SWAMPY HANDBOOK

## SWAMPER ADVENTURES



# SWAMPY HANDBOOK

- **SPEEDO CORRECTION & 10 MPH SPEED LIMIT REDUCTION**

- SINGLE CARRIAGEWAYS: 50MPH
- DUAL CARRIAGEWAYS: 60MPH
- MOTORWAYS: 70MPH

*PLEASE REMEMBER THE SPEEDO IS OUT BY 10%*

*30MPH ON THE SPEEDO MEANS YOU'RE ACTUALLY DOING 33MPH*

*70MPH ON THE SPEEDO IS ACTUALLY 77MPH.*

- **OPENING & CLOSING OF POP TOP INCLUDING CLIPS**

OPEN- RELEASE BOTH RATCHET STRAPS AND PLACE SOMEWHERE SAFE > PUSH POP TOP AND TOP BED UPWARDS.

CLOSE — PULL DOWN BED > GRAB BOTH HANDLES AND PULL POP TOP DOWN ENSURING CANVAS IS BEING PULLED INWARDS INTO THE VAN > TUCK ALL EXCESS CANVAS INTO PERIMETER EDGES AND REAPPLY RATCHET STRAPS ENSURING THEY ARE TIGHT.

- **ISOLATION & USE OF GAS HOB**

THE GAS BOTTLE IS LOCATED FROM THE REAR OF THE VAN IN THE BOTTOM CORNER CUPBOARD. THERE IS A BLACK KNOB THAT TURNS THE GAS ON AND OFF. WHEN USING THE GAS HOB, A WINDOW OR DOOR MUST BE OPEN TO RELEASE AND GAS AND PREVENT A BUILD-UP. AFTER USE, LET HOB COOL BEFORE CLOSING GLASS LID. ENSURE THE GAS IS TURNED OFF AFTER USE ON THE HOB AND BOTTLE.

- **WATER & WASTE**

THERE IS A 30L WATER TANK LOCATED UNDERNEATH THE VAN. SHOULD YOU RUN OUT, YOU CAN TOP UP USING THE JUG AND FUNNEL THAT IS LOCATED IN THE REAR WARDROBE. THE FILLER CAP IS LOCATED ON THE DRIVER SIDE REAR OF THE VAN. THE WASTE FROM THE SINK RUNS DIRECTLY TO OUTSIDE VIA THE GREY PIPE NEAR THE BACK WHEEL.

- **FRIDGE/FREEZER**

THE FRIDGE/FREEZER WORKS FROM THE LEISURE BATTERY OR FROM THE EHU IF YOU ARE PLUGGED IN. TO TURN ON JUST PRESS & HOLD THE POWER BUTTON INSIDE THE FRIDGE. THE BUTTON ON THE RIGHT IS TO ALTER THE TEMPERATURE.

- **USE OF LEISURE BATTERY CONTROL PANEL**

THE ONLY SWITCH YOU WILL NEED TO OPERATE ON THIS CONTROL PANEL IS THE ONE FOR THE LIGHTS. UPON SWITCHING THE LIGHTS ON, YOU CAN THEN TURN THEM OFF INDIVIDUALLY SHOULD YOU NOT WANT THEM ALL ON. THEY ARE TOUCH SENSITIVE AND OFFER ON, OFF OR BLUE.

THE 3-PIN PLUG WILL ONLY WORK WHILST YOU ARE ON ELECTRIC HOOK UP (EHU). THIS PLUG WILL NOT WORK OFF THE LEISURE BATTERY. PLEASE AVOID USING HIGH WATTAGE APPLIANCES SUCH AS HAIR DRYERS AND STRAIGHTENERS.

## • USE OF DOUBLE SWIVEL SEAT

THE DOUBLE PASSENGER BENCH CAN ROTATE 180 OFFERING MORE SEATING AND SPACE IN THE SEATING AREA. TO DO THIS YOU WILL NEED TO PLACE THE VAN IN 1<sup>ST</sup> GEAR AND RELEASE THE HANDBRAKE. ONCE THE HANDBRAKE IS DOWN YOU NEED TO LOOSEN THE 4 BOLTS (2 FRONT, 2 REAR) JUST ENOUGH SO THAT THE PIN CAN BE PULLED THROUGH THE BOLT MECHANISM. WITH THE BOLTS LOOSENERED, OPEN THE PASSENGER DOOR. FROM THE REAR, PUSH THE BENCH FORWARD PUSHING SLIGHTLY TOWARDS THE STEERING WHEEL. THEN YOU WILL BE ABLE TO START PIVOTING THE SEAT AND MANOEUVRING IT AROUND UNTIL IT IS FACING THE OPPOSITE WAY. KEEP AN EYE ON THE DRIVER SEAT ARM AS IT WILL GET IN THE WAY AT TIMES. ONCE IT HAS BEEN ROTATED. LOCK THE BOLTS BACK AND LIFT THE HANDBRAKE BACK UP.

## • ROCK N ROLL BED

SLACKEN SEAT BELTS BY GRABBING THEM AND PULLING TOWARDS YOU, THEN GRAB THE BLACK METAL HANDLE AT THE FRONT OF THE ROCK AND ROLL BED AND LIFT/PULL TO RELEASE THE MECHANISM. TO TURN BACK INTO THE SEATING POSITION, PUSH THE SILVER BUTTON ON THE B PILLAR WHERE THE DOUBLE PASSENGER BENCH IS AND YOU WILL HEAR THE LOCK RELEASE. THEN GRAB THE TIE HANDLE IN-BETWEEN THE SEATBELTS AND PULL UPWARDS. ONCE YOU START TO WALK THE BED BACK INTO A SEATING POSITION, MAKE SURE YOU GRAB AND LIFT THE BLACK METAL HANDLE AT THE FRONT OF THE BED.

## • LOCKING OF VEHICLE AT NIGHT WITHOUT USING ALARM

IF YOU WISH TO LOCK THE VAN AT NIGHT, YOU CAN DO SO BY PRESSING THE LOCK BUTTON ON THE DRIVER SIDE WINDOW CONTROL PANEL.

## • ELECTRIC HOOK UP POINT (EHU)

THIS IS LOCATED AT THE REAR OF THE VAN, BOTTOM RIGHT. JUST REMOVE THE WHITE PROTECTIVE CAP AND PLUG IN THE CABLE WHICH IS LOCATED AT THE REAR STORAGE AREA CUPBOARD. ONCE PLUGGED IN THE 3-PIN PLUG WILL WORK.

- MOST CAMPsite EHUs PROVIDE 10A (2,300W) OR 16A (3,680W) CONNECTIONS.
- SOME SITES MAY ONLY OFFER 6A (1,380W), WHICH IS VERY LIMITED.
- A STANDARD HAIR DRYER MAY TRIP THE BREAKER SO IF POSSIBLE PLEASE USE THE ELECTRICS AT THE CAMPsite OR USE A LOW WATTAGE TRAVEL HAIR DRYER.

## • REMOVAL OF BEDDING SHEET

ONCE YOU HAVE FINISHED YOUR STAY, PLEASE REMOVE THE GREY BED SHEET, AND LEAVE ON A SEAT.

## • FUEL CAP (DIESEL ONLY)

THE FUEL CAP IS LOCATED BY THE PASSENGER DOOR AND YOU MUST OPEN THE PASSENGER DOOR TO GAIN ACCESS TO THE FUEL CAP. PLEASE RETURN THE VAN WITH A FULL TANK OF DIESEL.

## • Fiamma F45s AWNING (DO NOT USE IN STRONG WINDS)

TO OPEN THE AWNING, REMOVE THE HANDLE FROM THE REAR OF THE VAN WHICH IS MOUNTED AT THE TOP BULKHEAD. PLACE THE HANDLE IN THE FAR-RIGHT LOOP AND START WINDING. IF THERE ARE TWO PEOPLE, IT IS HELPFUL IF THE OTHER PERSON SUPPORTS THE WEIGHT OF THE BLACK END PIECE WHILST THE OTHER WINDS IT OUT. ONCE IT IS WOUND OUT FULLY, TAKE IT BACK A TURN TO TIGHTEN THE CANVAS. THEN REMOVE THE LEGS FROM THE BLACK END PIECE WHICH ARE ON THE INSIDE IN THE RECESS. ONCE HAPPY WITH HEIGHT ETC, PEG THE LEGS SECURELY INTO THE GROUND AS WELL AS USING THE STORM STRAPS INCLUDED.

- STORM STRAPS MUST BE USED AT ALL TIMES, EVEN IF YOU DON'T THINK IT'S WINDY.

## • **DIESEL NIGHT HEATER**

THE VAN IS EQUIPPED WITH A DIESEL HEATER THAT IS PLUMBED INTO THE MAIN FUEL TANK. YOU CAN OPERATE THIS VIA THE MAIN CONTROL PANEL ON THE DRIVERS B PILLAR OR VIA THE REMOTE ON THE VANS KEYRING. WHEN USING THE REMOTE, PLEASE HOLD A BUTTON FOR A COUPLE OF SECONDS. A SINGLE PRESS WILL NOT WORK.

YOU HAVE TWO OPERATION SETTINGS ON THE HEATER, FAN SPEED AND TEMPERATURE. TO SWITCH IN BETWEEN THE 2 SETTINGS, PLEASE PRESS AND HOLD THE TOP LEFT BUTTON ON THE CONTROL PANEL. WE ALSO PROVIDE A LOW WATTAGE OIL HEATER & FAN HEATER.

- THE REMOTE WILL ONLY ADJUST WHICH EVER SETTING WAS LAST USED ON THE CONTROL PANEL.
- THE HEATER WILL NOT WORK IF THE LEISURE BATTERY IS LOW AND YOU ARE OFF GRID – RUN THE ENGINE AND FLICK THE SWITCH FROM ‘LEISURE’ TO ‘MAIN’ ON THE LEISURE CONTROL BATTERY CONTROL PANEL.
- IF THE FUEL TANK IS LOW THE HEATER WILL NOT WORK TO PRESERVE THE FUEL. RE-FILL.

## • **FRONT SCREEN BLACKOUT COVER**

LOCATED UNDER THE FRONT PASSENGER SEAT. HOLD IN PLACE BY TRAPPING THE EDGES IN THE FRONT DOORS

## **WHAT IS PROVIDED**

- ROCK N ROLL FOAM BED MATTRESS TOPPER WITH FITTED SHEET
- 2 X FOLDING CAMPING CHAIRS WITH FAUX MINK THROWS
- FOLDABLE SMALL DINING TABLE
- FIREMAPLE CAMPING COOKWARE SET COMPRISING OF GRIDDLE, POT KETTLE & 2 X PANS
- 4x PLATES, BOWLS, MUGS AND TUMBLERS AND 4 SETS OF CUTLERY
- 3 PIN PLUG TOASTER WHICH REQUIRES EHU (ELECTRIC HOOK UP)
- SWAMPER WELCOME HAMPER
- GAS BOTTLE AND 30L OF WATER

## **OPTIONAL AT NO EXTRA COST**

- INFLATABLE MATTRESS FOR POP TOP.
- SMALL 3 PIN ELECTRIC OVEN (REQUIRES ELECTRIC HOOK UP)
- 3 PIN PLUG TOASTER WHICH (REQUIRES ELECTRIC HOOK UP)

## **NOT PROVIDED**

- PILLOWS & BEDDING
- FOOD & DRINK

WE HOPE YOU ENJOY YOUR STAY

**SWAMPER ADVENTURES**



SWAMPER  
ADVENTURES